159



Brand: Excalibur
Product Code: 159
Stock: 2 - 3 Days
UPC: 289538969038
MPN: 159-03
Location: Cleveland, Ohio

Price: $99.99

Short Description
Excalibur 159-03 2-Way 1/4-Mile Range LCD Remote Control

Description
Brand NEW Excalibur 159-03E 2-Way 1/4-Mile Range LCD Remote Control Transmitter

The Excalibur 159-03E 2-way 1/4-mile is one of Excalibur's premium LCD screen remote control. Do you have a compatible Excalibur systems? You can replace those remotes with this Excalibur remote control. Reference the application table below.

This remote control is new from the original manufacturer ensuring that you are receiving a genuine product made for your Excalibur system.

Works with the following Excalibur systems:

- AL-1850-EDPB
- AL-1851-EDPB
- AL-1860-EDPB
- AL-1920-EDP
- AL-1950-EDPB
- ECHO-1
- ECHO-2

- ECHO-3
- ECHO-4
- ECHO-5
- ECHO-TOUCH
- EL-10
- EN-28
- RF-51-EDP

Will replace the following remote Excalibur remote controls:

- 151-03G
- 151-05G
- 151-07
- 152-03G
- 151-03G
- 152-05CF
- 152-07
- 154-03
- 154-05
- 154-07
- 155-03
- 155-07
- 158-03
- 158-07
- 159-03
- 791-03
- 791-07

Please make sure you have a working control unit installed in the vehicle prior to ordering this remote control. Programming instructions are included in the package and will require accessing your valet/programming switch.

Please contact us if you have any questions.

PROGRAMMING INSTRUCTIONS:

Standard Programming: This method to program additional or replacement transmitters does not affect the Unauthorized Transmitter Alert (UTA) feature. Before you begin, have all transmitters which are to operate the system at hand.

1. Turn the ignition “on”.
2. Within 5 seconds of Step 1, press the Valet Switch 5 times. The siren/horn will briefly sound, confirming that the system is ready to learn a transmitter code.
3. Press the “lock” button on the transmitter. The system will chirp the siren/horn once to confirm that the remote was learned.
4. If a code is not received within 10 seconds of Step 2, the learning process will automatically exit.

Programming Instructions

Standard Programming: This method to program additional or replacement transmitters does not affect the Unauthorized Transmitter Alert (UTA) feature. Before you begin, have all transmitters which are to operate the system at hand.

1. Turn the ignition “on”.
2. Within 5 seconds of Step 1, press the Valet Switch 5 times. The siren/horn will briefly sound, confirming that the system is ready to learn a transmitter code.
3. Press the “lock” button on the transmitter. The system will chirp the siren/horn once to confirm that the remote was learned.
4. If a code is not received within 10 seconds of Step 2, the learning process will automatically exit.

Specification

Remote Control	
Works With Antenna(s)	433 ECHO
Battery Type	CR2032 (X2)
FCC ID	ELVNTRNC
IC Number	
Frequency	434Mhz
Range	1/4-MILE
1-Way or 2-Way	2-WAY