1111

Brand: Excalibur
Product Code: 1111
Stock: 4
UPC: 289538969908
MPN: 1111-03E
Location: Cleveland, Ohio

Price: $44.99

Short Description
Excalibur 1111 1-Way 1-Mile Range LED Remote Control

Description
Brand NEW Excalibur 1111-03E 1-Way 1-Mile Range Remote Control Transmitter

The Excalibur 1111-03E is the 1-way companion remote control to Excalibur's premium LED 2-way 1-mile 1110 remote control. Do you have a compatible Excalibur systems? You can replace those remotes with this Excalibur remote control. Reference the application table below.

This remote control is new from the original manufacturer ensuring that you are receiving a genuine product made for your Excalibur system.

Works with the following Excalibur systems:

- AL-1575
- AL-1775-3DB
- RS-272
- RS-276-3D
- RS-375
- RS-375-3D
- RS-375-3DB
- RS-475-3D

Will replace the following remote Excalibur remote controls:

- 124
- 1110
- 1111
- 1412
- 1511

Please make sure you have a working control unit installed in the vehicle prior to ordering this remote control. Programming instructions are included in the package and will require accessing your valet/programming switch.

Please contact us if you have any questions.

PROGRAMMING INSTRUCTIONS:

Standard Programming: This method to program additional or replacement transmitters does not affect the Unauthorized Transmitter Alert (UTA) feature. Before you begin, have all transmitters which are to operate the system at hand.

1. Turn the ignition “on”.
2. Within 5 seconds of Step 1, press the Valet Switch 5 times. The siren/horn will briefly sound, confirming that the system is ready to learn a transmitter code.
3. Press the “lock” button on the transmitter. The system will chirp the siren/horn once to confirm that the remote was learned.
4. If a code is not received within 10 seconds of Step 2, the learning process will automatically exit.

Programming Instructions

Standard Programming: This method to program additional or replacement transmitters does not affect the Unauthorized Transmitter Alert (UTA) feature. Before you begin, have all transmitters which are to operate the system at hand.

1. Turn the ignition “on”.
2. Within 5 seconds of Step 1, press the Valet Switch 5 times. The siren/horn will

briefly sound, confirming that the system is ready to learn a transmitter code.

3. Press the “lock” button on the transmitter. The system will chirp the siren/horn once to confirm that the remote was learned.
4. If a code is not received within 10 seconds of Step 2, the learning process will automatically exit.

Specification

Remote Control	
Works With Antenna(s)	3D SST ECHO 2 WAY READY 70-SERIES ONLY
Battery Type	CR2032
FCC ID	ELVATQH
Frequency	900Mhz
Range	1-MILE
1-Way or 2-Way	1-WAY