

# 1417



**Brand:** Excalibur

**Product Code:** 1417

**Availability:** 4

**UPC:** 289538972373

**FCC ID:** ELVNTQE

**MPN:** 1417

**Location:** Cleveland, Ohio

**Price:** \$39.99

## Short Description

Excalibur 1417 1-Way 1/4-Mile Range Remote Control

## Description

**Brand NEW Excalibur 1417 1-Way 1/4-Mile Range Remote Control Transmitter**

The Excalibur 1417 is Excalibur's basic 1-way 1/4-mile 4-button remote control. Do you have a compatible Excalibur systems? You can replace those remotes with this Excalibur remote control. Reference the application table below.

This remote control is new from the original manufacturer ensuring that you are receiving a genuine product made for your Excalibur system.

## Works with the following Excalibur systems:

- AL-1670-B
- AL-1870-3DB
- RS-270
- RS-271
- RS-272
- RS-275-3DB
- RS-370

## **Will replace the following remote Excalibur remote controls:**

- 118
- 123
- 1415
- 1416
- 1510

Please make sure you have a working control unit installed in the vehicle prior to ordering this remote control. Programming instructions are included in the package and will require accessing your valet/programming switch.

Please contact us if you have any questions.

## **PROGRAMMING INSTRUCTIONS:**

Standard Programming: This method to program additional or replacement transmitters does not affect the Unauthorized Transmitter Alert (UTA) feature. Before you begin, have all transmitters which are to operate the system at hand.

1. Turn the ignition “on”.
2. Within 5 seconds of Step 1, press the Valet Switch 5 times. The siren/horn will briefly sound, confirming that the system is ready to learn a transmitter code.
3. Press the “lock” button on the transmitter. The system will chirp the siren/horn once to confirm that the remote was learned.
4. If a code is not received within 10 seconds of Step 2, the learning process will automatically exit.

## **Programming Instructions**

Standard Programming: This method to program additional or replacement transmitters does not affect the Unauthorized Transmitter Alert (UTA) feature. Before you begin, have all transmitters which are to operate the system at hand.

1. Turn the ignition “on”.
2. Within 5 seconds of Step 1, press the Valet Switch 5 times. The siren/horn will briefly sound, confirming that the system is ready to learn a transmitter code.
3. Press the “lock” button on the transmitter. The system will chirp the siren/horn once to confirm that the remote was learned.
4. If a code is not received within 10 seconds of Step 2, the learning process will automatically exit.

## Specification

Remote Control	
Works With Antenna(s)	3D 433 ECHO 2 WAY READY 70-SERIES
Battery Type	CR2016 (X2)
FCC ID	ELVNTQE
Frequency	433Mhz
Range	1/4-MILE
1-Way or 2-Way	1-WAY