

## ASDS-3520



**Brand:** AutoStart

**Product Code:** ASDS-3520 - 7858V

**Availability:** 4

**FCC ID:** EZSDEI7856

**MPN:** ASDS-3520

**Location:** Cleveland, Ohio

**Price:** \$136.99

### Short Description

AutoStart 2-Way LED 1-Mile Remote Control

### Description

**Introducing The NEW Viper 7858V 2-way LED Remote Control Transmitter Replacing The Discontinued Autostart ASDS-3520**

Upgrade your Autostart security, remote start or security with remote start system with this newly redesigned Viper 7858V 2-Way LED remote control, built to pair seamlessly with the latest Autostart systems including the Digital DS3 - DS4 Systems.

This sleek new design features a slimmer profile for enhanced comfort and convenience, along with an upgraded USB-C charging port for improved reliability and longevity. The intuitive layout places the remote buttons on the right for quick access, while the LED command confirming LED's are conveniently located on the left side of the buttons for a streamlined user experience - No more battery replacements!

Whether you're replacing a lost remote or adding an extra for convenience, the 7858V is the perfect solution. Shop with confidence at Access 1 Alarm and Audio — where you'll receive a brand-new, **GENUINE** remote control direct from the original manufacturer. No knock-offs. No reprogrammed returns. Just authentic

Viper and Autostart quality.

**Works with the following Autostart systems:**

- DS3
- DS3+
- DS4
- DS4+
- DS4AF
- DS4AFP
- DS4V
- DS4VP
- AS-2386TWS
- AS-RFD1554
- AS-RFD3520
- AS-RFD7506

**Works with the following Polar Start and Premier Defense systems:**

- PS-7880TWS
- PS-4686TWS
- PD485

Please make sure you have a working control unit installed in the vehicle prior to ordering this remote control. Programming instructions are included with the package and will require accessing your windshield mounted valet/programming switch. Video instructions will be available on our YouTube page under remote controls.

**Programming Your Remote Control**

**Note:** Make sure the system is disarmed, and the Control Center LED is completely OFF for a minimum of 60-seconds prior to beginning the remote pairing process.

Preparing the system

1. Driver's door OPEN
2. Turn the ignition ON.
3. Within 10-seconds, press and release once, then press and hold the

system's Control Center (The Windshield Mounted Antenna) Valet button. The status LED begins flashing and the siren/horn (if connected) sounds to confirm the system is ready for pairing.

4. Release the Control Center's Valet button.

### Pairing the remote control

1. Press and hold the UNLOCK button (approximately 8-seconds) until the remote enters pairing mode and emits a long beep.
2. Release the UNLOCK button.
3. Within 2 seconds, Press and release UNLOCK once more.
4. After a short delay, the horn/siren sounds (if connected) and the Parking Lights flash to confirm the system has paired with the remote control.
5. Turn the ignition OFF and WAIT approximately 60 seconds for the remote control to exit pairing mode.

**Note:** 2-Way remotes will emit tones and provide visual confirmation that the remote has successfully paired with the system. 1-Way remotes do not offer pairing confirmation.

**Why buy from us?** Well, we are the experts that only believe in perfection, from the quality of our images to the accurate description in each and every listing. Please contact us with any questions or ordering assistance..

---

## Programming Instructions

### Programming Your Remote Control

**Note:** Make sure the system is disarmed, and the Control Center LED is completely OFF for a minimum of 60-seconds prior to beginning the remote pairing process.

### Preparing the system

1. Driver's door OPEN
2. Turn the ignition ON.
3. Within 10-seconds, press and release once, then press and hold the system's Control Center (The Windshield Mounted Antenna) Valet button.

The status LED begins flashing and the siren/horn (if connected) sounds to confirm the system is ready for pairing.

4. Release the Control Center's Valet button.

### Pairing the remote control

1. Press and hold the UNLOCK button (approximately 8-seconds) until the remote enters pairing mode and emits a long beep.
2. Release the UNLOCK button.
3. Within 2 seconds, Press and release UNLOCK once more.
4. After a short delay, the horn/siren sounds (if connected) and the Parking Lights flash to confirm the system has paired with the remote control.
5. Turn the ignition OFF and WAIT approximately 60 seconds for the remote control to exit pairing mode.

**Note:** 2-Way remotes will emit tones and provide visual confirmation that the remote has successfully paired with the system. 1-Way remotes do not offer pairing confirmation.

### Specification

Remote Control	
Works With Antenna(s)	6866T, 6867T, TW-151
Battery Type	CR2016 (X2)
FCC ID	EZSDEI7856
IC Number	
Frequency	915MHZ
Range	1-Mile+
1-Way or 2-Way	2-WAY