

Viper 7345V + 7145V 2-Way LCD & 1-Way Remote Control Bundle



Brand: Viper

Product Code: 7345V + 7145V

Stock: 3

UPC: 093207095009

FCC ID: EZSDEI489

MPN: Viper 7345V + 7145V

Location: Cleveland, OH

Price: \$179.99

Short Description

Get two genuine Viper remotes in one package: the **7345V 2-Way Responder LCD remote** plus the **7145V 1-Way companion remote** for compatible Viper and Directed security and remote-start systems. **\$179.99 with FREE U.S. shipping.**

Description

Genuine Viper 7345V + 7145V Remote Control Bundle

Get two genuine Viper remote controls for your compatible security or remote-start system with this **Viper 7345V + 7145V remote-control bundle.**

The bundle combines the full-featured **7345V 2-Way Responder LCD remote** with a **7145V 1-Way companion remote**, giving you a primary LCD remote plus a convenient second remote for another driver, spare key set or backup.

\$179.99 FREE Shipping in the USA

2 GENUINE VIPER REMOTES Brand-new original Viper remote controls

7345V 2-WAY LCD Visual and audible command confirmation

7145V 1-WAY Convenient companion or backup remote

UP TO 1/4 MILE Long-range operation with compatible systems

What's Included in the 7345V + 7145V Bundle?

Viper 7345V — 2-Way LCD Remote Your primary remote provides 2-way communication with the compatible security or remote-start system. The LCD display provides visual and audible confirmation of supported commands and system status.

Viper 7145V — 1-Way Remote The 7145V provides a simple second remote for controlling compatible system functions. It is ideal for a second driver, additional key set or as a backup remote.

Two Viper Remote Controls for One Compatible System

Instead of purchasing only one replacement remote, this package gives you both a **Viper**

7345V 2-way LCD remote and a **Viper 7145V 1-way remote** for use with the same compatible Viper or Directed security and remote-start system.

Use the 7345V as your primary remote when you want 2-way confirmation from the system and keep the 7145V with another set of keys or give it to another driver who doesn't need the LCD display.

Both remotes are **brand-new genuine Viper products** from the original manufacturer — not used, refurbished or reprogrammed remote controls.

7345V Compatible & Replacement Remote Models

This bundle is intended for compatible systems that use the Viper 7345V remote platform. The 7345V can be used with compatible systems that originally operated with the following remote controls:

VIPER 489V 7341V
PYTHON 489P 7341P
CLIFFORD 489X 489XD 7341X 7345X
AUTOMATE 7344A
AVITAL 7345L

Viper 7345V + 7145V System Compatibility

This remote-control bundle works with select Viper, Python, Clifford Matrix, Automate, Avital and Mesa security and remote-start systems using a compatible receiver / Control Center.

VIPER

- 3305V
- 4305V
- 5305V
- Responder 350
- 5000
- 5002

PYTHON

- Responder 460
- 3305P
- 5305P
- 900
- 902

CLIFFORD MATRIX

- Matrix 1X
- Matrix 10.5
- Matrix 12.5X
- 3305X
- Matrix 5305X
- 5305

- Matrix 5325X

AUTOMATE

- 5305A

AVITAL

- 3305L
- 5305

MESA

- 3307VM
- 5307VM

IMPORTANT COMPATIBILITY INFORMATION:

Remote-control compatibility is determined by the **security/remote-start system and receiver / Control Center installed in the vehicle**, not by the vehicle's year, make or model.

If a **Viper 7345V previously operated your system**, this bundle is designed to provide a genuine 7345V replacement along with the compatible 7145V 1-way companion remote.

If you are replacing a different remote-control model, verify the original remote number and installed system before ordering. Compatibility can depend on the system model, date code and Control Center / Antenna installed in the vehicle.

Remote Programming: Both remote controls must be paired with the compatible security or remote-start system installed in the vehicle before use. Programming requires access to the system's Valet / Program switch or windshield-mounted Control Center / Antenna.

Complete programming information is provided separately in the **Programming Instructions** tab on this page.

```
{ "@context": "https://schema.org", "@type": "Product", "@id": "https://www.access1alarm.com/car-alarms-and-remote-start/remote-controls/viper/7345v/7345v-7145v-remote-control-bundle#product", "url": "https://www.access1alarm.com/car-alarms-and-remote-start/remote-controls/viper/7345v/7345v-7145v-remote-control-bundle", "name": "Viper 7345V + 7145V Remote Control Bundle", "description": "Genuine Viper remote-control bundle containing one 7345V 2-way LCD remote and one 7145V 1-way companion remote for compatible Viper and Directed security and remote-start systems.", "image": "https://www.access1alarm.com/images/com_eshop/products/7345v-7145v-remote-control-combo.jpg", "sku": "7345V-7145V", "mpn": "7345V-7145V", "brand": { "@type": "Brand", "name": "Viper" }, "additionalProperty": [ { "@type": "PropertyValue", "name": "Primary Remote", "value": "Viper 7345V 2-Way LCD" }, { "@type": "PropertyValue", "name": "Companion Remote", "value": "Viper 7145V 1-Way" }, { "@type": "PropertyValue", "name": "Quantity", "value": "2 Remote Controls" }, { "@type": "PropertyValue", "name": "Operating Range", "value": "Up to 1/4 Mile with compatible systems" } ], "offers": { "@type": "Offer", "url": "https://www.access1alarm.com/car-alarms-and-remote-start/remote-controls/viper/7345v/7345v-7145v-remote-control-bundle", "priceCurrency": "USD", "price": "179.99", "availability": "https://schema.org/InStock", "itemCondition": "https://schema.org/NewCondition", "shippingDetails": { "@type": "OfferShippingDetails", "shippingRate": { "@type": "MonetaryAmount", "value": "0", "currency": "USD" }, "shippingDestination": { "@type": "DefinedRegion", "addressCountry": "US" } }, "seller": { "@type": "Organization", "name": "Access 1 Alarm & Audio", "url": "https://www.access1alarm.com/" } } }
```

Programming Instructions

Viper 7345V Remote Control Programming Instructions

The **Viper 7345V** must be paired to the security or remote-start system installed in the vehicle before it can be used.

The correct programming procedure depends on whether your installed system is a **Security + Remote Start system** or a **Security Only system**.

IMPORTANT — LOCATE YOUR PROGRAMMING BUTTON FIRST

Depending on the age and configuration of your system, the programming button may be located in one of two places:

- **Separate Valet / Program Switch:** Older installations may have a separate small push-button switch hidden underneath the driver's side dashboard.
- **Control Center / Antenna:** Other systems use the programming button incorporated into the windshield-mounted Control Center / Antenna.

Both buttons serve the same programming purpose in the routines below. Use whichever programming button is installed with your system.

1. **Door:** Open a vehicle door and leave it open.
2. **Key:** Turn the ignition key to the **ON** position. Do not start the vehicle.

3. **Choose:** Within five seconds, press and release the **Valet / Program button or Control Center / Antenna button one time.**
4. **Hold:** Within five seconds, press the same programming button one more time and **continue holding it.** The LED will flash one time and the siren will chirp to confirm entry into remote programming. **Do not release the button.**
5. **Transmit:** While continuing to hold the programming button, press the **LOCK button** on the Viper 7345V. The siren will chirp to confirm that the remote has been programmed.
6. **Release:** Release the programming button and turn the ignition key to **OFF.**

1. **Door:** Open a vehicle door and leave it open.
2. **Key:** Turn the ignition key to the **ON** position. Do not start the vehicle.
3. **Choose:** Within five seconds, press and release the **Valet / Program button or Control Center / Antenna button seven times.**
4. **Hold:** Press the same programming button one more time and **continue holding it.** The LED will flash seven times and the siren will chirp to confirm the selected programming channel. **Do not release the button.**
5. **Transmit:** While continuing to hold the programming button, press the **LOCK button** on the Viper 7345V. The unit will chirp to confirm that the remote has been paired to the receiver.
6. **Release:** Release the programming button and turn the ignition key to **OFF.**

NOTE: If the system does not enter programming mode, first verify that you are using the correct programming button for your installation. Some vehicles have the **Valet / Program switch hidden underneath the dashboard**, while others use the button on the **windshield-mounted Control Center / Antenna**.

Programming Complete

After programming is complete, turn the ignition OFF and test the Viper 7345V by locking and unlocking the system. A properly paired 2-way remote should provide confirmation from the compatible system.

Viper Remote Control Programming Video

Need additional help? Watch our remote-control programming video for a visual walkthrough of the pairing process.

WATCH PROGRAMMING VIDEO