

Viper 7347V + 7147VS 2-Way LCD & 1-Way Remote Control Bundle



Brand: Viper

Product Code: 7347V-7147VS

Stock: 2

UPC: 044476161544

FCC ID: EZS7347V

MPN: 7347V-7147VS

Location: Cleveland, Ohio

Price: \$169.99

Short Description

Get two genuine Viper remotes in one package: the **7347V 4th Generation 2-Way LCD remote** plus the **7147VS 1-Way security companion remote** for compatible Viper and Directed security systems. **\$169.99 with FREE U.S. shipping.**

Description

Genuine Viper 7347V + 7147VS Remote Control Bundle

Get the genuine Viper remote-control combination originally designed for compatible 2-way security and remote-start systems with this **Viper 7347V + 7147VS remote-control bundle.**

This package combines the **Viper 7347V 4th Generation 2-Way LCD remote** with the **Viper 7147VS 1-Way companion remote**, giving you a full-featured primary LCD

remote plus a convenient second remote for another driver, spare key set or backup.

\$169.99 FREE Shipping in the USA

2 GENUINE VIPER REMOTES Brand-new original Viper remote controls

7347V 2-WAY LCD Visual and audible command confirmation

7147VS 1-WAY Security companion or backup remote

UP TO 1/4 MILE Rated range with compatible systems

What's Included in the 7347V + 7147VS Bundle?

Viper 7347V — 2-Way LCD Remote The 7347V is the primary 4th-generation 2-way LCD remote. Its display provides visual and audible confirmation of supported commands and system status from compatible Viper and Directed systems.

Viper 7147VS — 1-Way Companion Remote The 7147VS is the matching 1-way security companion remote. It provides convenient control for another driver, additional key set or backup without the LCD display of the primary remote.

2-Way LCD Remote Plus 1-Way Companion Remote

The **7347V and 7147VS** are a natural remote-control combination for compatible Viper 2-way security systems. In fact, Viper systems such as the **3308V** were originally supplied with one 7347V 2-way LCD remote and one 7147VS 1-way companion remote.

Use the **7347V** as your primary remote when you want 2-way command confirmation and system-status information. Keep the **7147VS** with another set of keys, give it to a second driver or keep it available as a backup.

Both remote controls are **brand-new genuine Viper products** from the original manufacturer — not aftermarket reproductions, used remotes or reprogrammed returns.

7347V Compatible & Replacement Remote Models

The 7347V is Viper's newer 4th-generation 2-way LCD remote and can replace several earlier or discontinued remote-control models when used with a compatible system and receiver / Control Center.

VIPER 489V 7341V 7345V
PYTHON 489P 7341P
CLIFFORD 489X 489XD 7341X 7345X

AUTOMATE 7344A

AVITAL 7345L

7353L

Viper 7347V + 7147VS System Compatibility

This remote-control bundle works with select Viper, Python, Clifford Matrix, Automate, Avital and Mesa security and remote-start systems using a compatible receiver / Control Center.

VIPER

- 3305V
- 3308V
- 4305V
- 5305V
- 5308V
- Responder 350
- 5000
- 5002

PYTHON

- Responder 460
- 3305P
- 5305P
- 900
- 902

CLIFFORD MATRIX

- Matrix 1X
- Matrix 10.5
- Matrix 12.5X
- 3305X
- Matrix 5305X
- 5305
- Matrix 5325X

AUTOMATE

- 5305A

AVITAL

- 3305L
- 3308L
- 5305
- 5308L

MESA

- 3307VM
- 5307VM

IMPORTANT COMPATIBILITY INFORMATION:

Remote-control compatibility is determined by the **security / remote-start system and receiver / Control Center installed in the vehicle**, not by the vehicle's year, make or model.

If a **Viper 7347V** previously operated your system, you already know the 7347V portion of this bundle is compatible with your installed system.

The **7147VS is the security-system version of the 7147 companion remote**. If you are replacing a different remote or purchasing this bundle for a remote-start-only application, verify the installed system and receiver / Control Center before ordering.

Compatibility can depend on the actual system model and receiver / Control Center installed in the vehicle. If you are unsure, identify your existing remote-control or system model before ordering.

```
{ "@context": "https://schema.org", "@type": "Product", "@id": "https://www.access1alarm.com/car-alarms-and-remote-start/remote-controls/viper/7347v/7347v-7147vs-remote-control-bundle#product", "url": "https://www.access1alarm.com/car-alarms-and-remote-start/remote-controls/viper/7347v/7347v-7147vs-remote-control-bundle", "name": "Viper 7347V + 7147VS 2-Way LCD & 1-Way Remote Control Bundle", "description": "Genuine Viper remote-control bundle containing one 7347V 4th-generation 2-way LCD remote and one 7147VS 1-way security companion remote for compatible Viper and Directed security systems.", "image": "https://www.access1alarm.com/images/com_eshop/products/7347V-7147VS.jpg", "sku": "7347V-7147VS", "mpn": "7347V-7147VS", "brand": { "@type": "Brand", "name": "Viper" }, "additionalProperty": [ { "@type": "PropertyValue", "name": "Primary Remote", "value": "Viper 7347V 4th Generation 2-Way LCD" }, { "@type": "PropertyValue", "name": "Companion Remote", "value": "Viper 7147VS 1-Way Security Remote" }, { "@type": "PropertyValue", "name": "Number of Remotes", "value": "2" }, { "@type": "PropertyValue", "name": "Operating Range", "value": "Up to 1/4 Mile with compatible systems" }, { "@type": "PropertyValue", "name": "7347V FCC ID", "value": "EVS7347V" }, { "@type": "PropertyValue", "name": "7147VS FCC ID", "value": "EVS7147V" } ], "offers": { "@type": "Offer", "url": "https://www.access1alarm.com/car-alarms-and-remote-start/remote-controls/viper/7347v/7347v-7147vs-remote-control-bundle", "priceCurrency": "USD", "price": "169.99", "availability": "https://schema.org/InStock", "itemCondition": "https://schema.org/NewCondition", "shippingDetails": { "@type": "OfferShippingDetails", "shippingRate": { "@type": "MonetaryAmount", "value": "0", "currency": "USD" }, "shippingDestination": {
```

```
"@type": "DefinedRegion", "addressCountry": "US" } }, "seller": { "@type":  
"Organization", "name": "Access 1 Alarm & Audio", "url":  
"https://www.access1alarm.com/" } } }
```

Programming Instructions

Viper 7345V Remote Control Programming Instructions

The **Viper 7345V** must be paired to the security or remote-start system installed in the vehicle before it can be used.

The correct programming procedure depends on whether your installed system is a **Security + Remote Start system** or a **Security Only system**.

IMPORTANT — LOCATE YOUR PROGRAMMING BUTTON FIRST

Depending on the age and configuration of your system, the programming button may be located in one of two places:

- **Separate Valet / Program Switch:** Older installations may have a separate small push-button switch hidden underneath the driver's side dashboard.
- **Control Center / Antenna:** Other systems use the programming button incorporated into the windshield-mounted Control Center / Antenna.

Both buttons serve the same programming purpose in the routines below. Use whichever programming button is installed with your system.

1. **Door:** Open a vehicle door and leave it open.
2. **Key:** Turn the ignition key to the **ON** position. Do not start the vehicle.
3. **Choose:** Within five seconds, press and release the **Valet / Program button or Control Center / Antenna button one time**.
4. **Hold:** Within five seconds, press the same programming button one more time and **continue holding it**. The LED will flash one time and the siren will chirp to confirm entry into remote programming. **Do not release the button**.
5. **Transmit:** While continuing to hold the programming button, press the **LOCK button** on the Viper 7345V. The siren will chirp to confirm that the remote has been programmed.
6. **Release:** Release the programming button and turn the ignition key to **OFF**.

1. **Door:** Open a vehicle door and leave it open.
2. **Key:** Turn the ignition key to the **ON** position. Do not start the vehicle.
3. **Choose:** Within five seconds, press and release the **Valet / Program button or Control Center / Antenna button seven times**.
4. **Hold:** Press the same programming button one more time and **continue holding it**. The LED will flash seven times and the siren will chirp to confirm the selected programming channel. **Do not release the button**.
5. **Transmit:** While continuing to hold the programming button, press the **LOCK button** on the Viper 7345V. The unit will chirp to confirm that the remote has been paired to the receiver.
6. **Release:** Release the programming button and turn the ignition key to **OFF**.

NOTE: If the system does not enter programming mode, first verify that you are using the correct programming button for your installation. Some vehicles have the **Valet / Program switch hidden underneath the dashboard**, while others use the button on the **windshield-mounted Control Center / Antenna**.

Programming Complete

After programming is complete, turn the ignition OFF and test the Viper 7345V by locking and unlocking the system. A properly paired 2-way remote should provide confirmation from the compatible system.

Viper Remote Control Programming Video

Need additional help? Watch our remote-control programming video for a visual walkthrough of the pairing process.

WATCH PROGRAMMING VIDEO