7816V and 7616V 2-Way LED 1-Mile Remote Control Pair Combo

Brand: Viper
Product Code: 7816V-7616V
Stock: 4
UPC: 093207096785
MPN: 7816V-7616V 7817V-7617V
Location: Cleveland, Ohio

Price: $169.99

Short Description
Viper LED 1-Button Remote Combo

Description

Brand NEW Viper 7817V 2-Way and 7617V 1-Way 1-Button 1-Mile Range Replacement Remote Control Transmitters For The Discontinued Viper 7816V and 7616V Remote Controls, Including The Clifford and Python Versions.

This NEW Viper 7817V and 7616V remote controls are the direct replacement for the discontinued 7816V/7616V that comes standard for many of the Viper systems such as the 4816V and D9816V systems. Looking for a replacement Viper remote control for your system or just need an additional remote control? Buy brand new from Access 1 Alarm and Audio!

Have one of the older systems with the 7816V-7616V remote controls? These are the new and improved version of those remote controls. This is Viper's 2nd generation of this style remote control and they are redesigned with improved reliability, range and ergonomics. Battery replacement is much easier also. This remote control will also replace the AstroStart 2621D-TX, Automate 7816V, Avital 7817L, Clifford 7816X and

the Python 7816P remote controls.

Whether you’re replacing a lost remote or adding an extra for convenience, this 7817V-7617V combo is the perfect solution. Shop with confidence at Access 1 Alarm and Audio — where you'll receive brand-new, **GENUINE** remote controls direct from the original manufacturer. No knock-offs. No reprogrammed returns. Just authentic Viper quality.

What you will receive NEW:

- 7817V 2-Way Remote Control
- 7617V 1-Way Remote Control
- Remote Control Owner's Manual (QR Link)
- Programming Instructions

Works with the following Viper systems

- 4811V
- 4816V
- 9816V
- D9816V
- DS4816V

Works with the following AstroStart systems

- AFRFD2621

Works with the following Automate systems

- 4816A
- D9816A

Works with the following Clifford systems

- 4811X
- 4816X
- 9816X
- D9816X

Works with the following Python systems

- 4811P
- 4816P
- 9816P
- D9816P

Please make sure you have a working control unit installed in the vehicle prior to ordering this remote control. Programming instructions are included with the package and will require accessing your windshield mounted antenna's valet/programming switch. Video instructions will be available on our YouTube page under remote controls. Please contact us if you have any questions.

Why buy from us? Well, we are the experts that only believe in perfection, from the quality of our images to the accurate description in each and every listing.

Programming Your Remote Control

Note: Make sure the system is disarmed, and the Control Center (windshield mounted antenna) LED is completely OFF for a minimum of 60-seconds prior to beginning the remote pairing process.

Preparing the system

1. Open drivers door
2. Turn the ignition ON.
3. Within 10-seconds, press and release once, then press and hold the system’s Control Center (The Windshield Mounted Antenna) Valet button. The status LED begins flashing and the siren/horn (if connected) sounds to confirm the system is ready for pairing.
4. Release the Control Center's Valet button.

Pairing the remote control

1. Press and hold the remote start button (approximately 8-seconds)
2. Wait for the Transmit LED to light solid and the remote to beep. Release the remote start button
3. Within 2 seconds, press and release the remote start button. Wait several seconds for the pairing to complete, the vehicle's horn will honk if connected. You have now successfully learned the remote control to the vehicle's remote start system.

4. Turn the ignition OFF and WAIT approximately 60 seconds.

Note: 2-Way remotes will emit tones and provide visual confirmation that the remote has successfully paired with the system. 1-Way remotes do not offer pairing confirmation.

Please contact us if you have any questions.